### **Map-A7R IV User Manual**

### Technical Parameter

**RESOLUTION** 61 magapixels

**IMAGE RESOLUTION** 9504\*6336

**SENOR SIZE** 35.7\*23.8mm

**PIXEL SIZE**  $3.7\mu m$ 

WEIGHT 220g(without lens)/540g(with 2-axis gimbal and 40mm lens)

**POWER SUPPLY** 9-28V TRIGGER TYPE **RELAY** 

**HOT SHOE SUPPORT** 

**GIMBAL TYPE** Brushless motor with encoder(2-AXIS /3-AXIS)

**DIMENSIONS** 115.8\*76.6\*40.6mm

LENS MOUNT SONY E

SHELL MATERIAL Aluminum alloy

**DATA COPY** USB3.0 or SD CARD

### Interface Definition



### **SONY E MOUNT**




## GH1.25 7pin cable interface:

DC 9-28V(3-6S): Power supply GND : Power ground SHOT : Camera trigger

Hotshoe :For PPK

Power supplied, camera auto power on

## Camera interface:



# FC settings (CUAV V5+ for example):

## Firmware before 4.2

Command	Value	
CAM_TRIGG_TYPE	1	Relay trigger
RELAY_PIN	55	Aux6 for trigger
BRD_PWM_COUNT	4 or less	e.g. set to 4 or less using the aux6 pin, otherwise aux6 will be considered to output the pwm signal
SERVO14_FUNCTION	10	Camera trigger
CAM_RELAY_ON	0	0 means low level trig camera

### Firmware after 4.2

Command	Value	FONTECHIPLO
CAM_TRIGG_TYPE	1	Relay trigger
RELAY_PIN	55	Aux6 for trigger
BRD_PWM_COUNT	4 or less	e.g. set to 4 or less using the aux6 pin, otherwise aux6 will be considered to output the pwm signal
SERVO14_FUNCTION	-1	GPIO
CAM_RELAY_ON	0	0 means low level trig camera